


FAZR

INSTALLATION INSTRUCTIONS




FAZR

PART 1: INSTALL ROCKFON® CARRIERS

Install Rockfon® Symmetrical Carriers per manufacturer instructions. See links for more information. **Carriers must be installed 2' OR 3' on center.**

<https://youtu.be/N-ynfgY7bRc?si=beIqsx0Lj4jxhfuj>

Once Rockfon® Symmetrical Carriers are installed, Part 1 is complete and you may proceed to installing the FAZR trapezoids in Part 2.



PART 1 INSTALLATION COMPLETE.

FAZR

PART 2: INSTALL FAZR TRAPEZOIDS


REQUIRED TOOLS



Utility Knife




Power Drill



Tape Measure

INCLUDED HARDWARE



PVC Extrusion




Sheet metal screws

INCLUDED COMPONENTS


Trapezoids come in 95" length and are cut in field. Configuration ordered determines width of trapezoids. The quantities provided will depend on the quantity ordered.

[Config 1]




Trapezoid
[Type 1]

[Config 2]




Trapezoid
[Type 1]

[Config 3]




Trapezoid
[Type 3]


[Config 4]



Trapezoid
[Type 3]




Trapezoid
[Type 2] (filler)




Trapezoid
[Type 4] (filler)

FAZR | PART 2: INSTALL FAZR TRAPEZOIDS

- 1 Determine the finished length and the amount to be cut and discarded from each trapezoid to accomplish the desired layout.




- 2 Cut the determined amount using a utility knife and a straight edge. Repeat for remaining trapezoids, including the fillers [Type 2 and Type 4].





FAZR | PART 2: INSTALL FAZR TRAPEZOIDS

- 3** Measure the distance between the wall and the center of first carrier.




- 4** Place 2 PVC extrusions on the Trapezoid [Type 1/3] as shown. The center of the extrusion should be at the distance determined in the previous step. Screw the self-tapping sheet metal screws in the the sides of the extrusions until tight. Do not overtighten!




FAZR | PART 2: INSTALL FAZR TRAPEZOIDS

- 5** Joining split Trapezoids can be done as shown, by fastening one extrusion on each Trapezoid, one on each side, with the middle of the extrusion falling on the end of the Trapezoid. The two Trapezoids can then be joined together using friction.




- 6** Insert one end of the Trapezoid [Type 1/3] into the carrier, hooking the PVC extrusion on either side of the metal hooks. Work down the length of the Trapezoid [Type 1/3] until it is fully seated in the metal carrier. Repeat for the remaining Trapezoids [Type 1/3].
Helpful Tip: the PET is flexible and can be flexed to fit the PVC extrusions into the metal hooks.




FAZR | PART 2: INSTALL FAZR TRAPEZOIDS

7 Repeat for the remaining Trapezoids [Type 1/3].



8 If the Configuration purchased [Config 1/Config 3] requires filler Trapezoids [Type 2/4], those can now be installed. Push in the legs of the filler Trapezoids [Type 2/4] and fit it between the installed Trapezoids [Type 1/3]. Work down the length until the filler Trapezoids [Type 2/4] are properly seated. Repeat for the remaining filler Trapezoids [Type 2/4].






PART 2 INSTALLATION COMPLETE.

FAZR


PART 3: INSTALL OPTIONAL LIGHT

REQUIRED TOOLS




INCLUDED HARDWARE


Quantities shown are for [1] single FAZR Linear Light




Aircraft Cable **3'**



Cable Gripper **x2**




Safety Loop Nut and Screw Set **x2**




Light Track Nut and Gripper Set **x2**

INCLUDED COMPONENTS




4' or 8' Linear Light **x1**



Driver **x1**



REQUIRED HARDWARE





Sheet metal screws **x2**

FAZR | PART 3: INSTALL OPTIONAL LIGHT

- 1 Identify the location of the light. If filler Trapezoids [Type 2/4] fill that space, remove them. Locate the hole in the top of the carrier that will be used to install the light. If one is not found, a 1/16" hole should be made using a drill.




- 2 Feed the Light Track Nut and Gripper Set into the open end of the track on the back of the linear light. Loosen the set screw on the side of the nut. Feed an end of the aircraft cable into nut, and tighten the set screw. Repeat at the other end of the light.




FAZR | PART 3: INSTALL OPTIONAL LIGHT



- 3** Feed the end of the aircraft cable into the hole located or created in the carrier. Then feed the end of that aircraft cable through the cable gripper. **The ridged end of the cable gripper must face up. The smooth end must fit in the hole made in the carrier.** Pull on the end of the cable until the light is cinched up to the carrier. Repeat for opposite end.



*Trapezoids hidden for clarity




- 4** Trim the excess aircraft cable. Loosen the screws on the sides of the Safety Loop Nut and Screw Set. Feed one end of the cable through one hole, then loop it back into the other. Tighten both screws.





FAZR | PART 3: INSTALL OPTIONAL LIGHT

- 5** Wire the Light Driver to a suitable power source. Locate the Light Driver close to the installed Linear Light, and attach it to the top of the carrier using zip ties. Lastly, wire the Linear Light to the Light Driver. A qualified electrician should complete this.



- 6** Re-install the Trapezoids adjacent to the light that may have been removed. Filler Trapezoids may be trimmed to fit the space around the Linear Light.



PART 3 INSTALLATION COMPLETE.